

# JetSort 3000-6000 Cleaning Procedures

Daily cleaning of JetSort machines is recommended to ensure maximum productivity and reliability.

## Recommended Cleaning Materials

### **CAUTION**

Simple Green, the recommended cleaning agent, can be an eye irritant. Avoid eye contact. If eye contact occurs, flush eye(s) with cool water for 5 minutes – remove contact lenses if present – continue flushing eye (s) with cool water for 15 more minutes. If irritation persists, consult physician.

Individuals with sensitive skin should rinse hands after using.

- Simple Green Safety Towels. (Part number: 022-2118-00.) A pre-moistened microfiber towel also may be used. If using Simple Green concentrate, dilute to: 30 ml of Simple Green per 240 ml of water. For material-safety-data sheets, see [simplegreen.com](http://simplegreen.com).
- Microfiber towels. (Part number: 022-2223-00.)
- Vacuum cleaner. (In the United States: Order standard vacuum part number 022-1959-00 or heavy-duty vacuum part number 022-1308-00. Outside of the United States: Buy vacuum locally.)

## Daily Cleaning

### **WARNING**

High-voltage levels may be present. Risk of electric shock.

Turn power OFF and unplug power cord from machine before cleaning.

### **NOTICE**

To avoid machine/component damage and potential voiding of existing warranty, follow these procedures:

Only use the specified tools for cleaning machine. Never use metal tools.

If using Simple Green concentrate, dilute to: 30 ml of Simple Green per 240 ml of water.

Never use cleaners containing ammonia. Ammonia may remove labels from machine.

Never spray cleaners directly on machine components.

## Cleaning JetSort Sorting Chamber

### **NOTICE**

Clean sort disk only as instructed. Do not attempt to remove oil coating on disk. Removing oil from disk negatively impacts performance and may negate disk warranty.

If disk cannot be cleaned with a clean, dry microfiber towel or cotton cloth, contact a Cummins Allison service representative for assistance.



Never wipe sort disk or pad, except as instructed in this document.

1. Remove coin tray to access the inside of the machine.
2. Remove any stray coins or other objects by hand.
3. Vacuum interior areas to remove accumulated dust or debris.
4. Raise and inspect sort disk.
5. Remove any debris by hand and clean disk if needed using dry microfiber towel, a clean cotton cloth, or a soft, non-metallic brush.

### NOTICE

Sort head damage can result from using metallic brush.

Use only soft, non-metallic brush as instructed by a Cummins Allison representative.

To prevent damage and to maintain coin-sorting function as designed, do not brush sort pad that rests on lower disk.

1. Lower sort disk and secure latch.



**Correct:** disk is secured



**Incorrect:** disk is not secured

2. Reinstall tray and secure in place.
3. Clean remaining **exterior** surfaces as needed with a Simple Green Safety Towel. If using Simple Green concentrate, dilute 1 part Simple Green with 8 parts water. Apply with microfiber towel.